Smart Lifestyle™
A U S T R A L I A

Heat Pump Water Heater

R290

Natural Refrigerant
Excellent Efficiency
Low GWP

Installation Guide

Product Models

- SLA-R18-190D/N4D4
- SLA-R25-250D/N4D4
- SLA-R25-300D/N4D4
- SLA-R18-190D/N4D4C
- SLA-R25-250D/N4D4C
- SLA-R25-300D/N4D4C

Installation Kits

Tempering Valve	**PTR Valve**	**PTR Valve Lagging**
Pressure Limiting Valve	**Non Return Valve**	**RCBO**
RCBO Switch Board	**General Power Outlet / Socket**	**Tube Joint**
Condensate Tube	**Manual** (Optional)	

Heat Pump Mode

SET TEMP 60℃ **WATER TEMP** 43℃ 15:55

SET · TIMER · MODE LOCK (M) · ON/OFF

Symbol	Description
	Fast Heating Mode (Hybrid)
	Electric Heater Mode
	Defrost Mode
	Fan Running indicator
	Lock Indicator
ON OFF	Timer ON and Timer OFF Indicator
88:88	Clock
SET TEMP 88℃	Setting value of Water Temperature
WATER TEMP 88℃	Current Value of Water Temperature

|	
1	PTR Valve
2	Hot Water Outlet
3	E-Heater
4	Temperature Sensor
5	Condensate Drainage
6	Overflow Outlet
7	Water Inlet

Position the heat pump on a flat sturdy surface.

Fix the tube joint and fit condensation tube to overflow port. Run it to a suitable drainage location.

Connect water supply to the water inlet.

Connect hot water outlet and PTR valve.

Connect supply water pipe and hot water pipe to the tempering valve.

ON/OFF

Switch power ON. Press and hold the ON/OFF button for 2 seconds to start the heat pump.

- SLA-R25-250D/N4D4
- SLA-R25-250D/N4D4C
- SLA-R25-300D/N4D4
- SLA-R25-300D/N4D4C

Position the heat pump on a flat sturdy surface.

Fix the tube joint and fit condensation tube to overflow port. Run it to a suitable drainage location.

Connect water supply to the water inlet.

Connect hot water outlet and PTR valve.

Connect supply water pipe and hot water pipe to the tempering valve.

ON/OFF

Switch power ON. Press and hold the ON/OFF button for 2 seconds to start the heat pump.

Maintenance space requirements

SLA-R18-190D/N4A4

SLA-R25-250D/N4D4
SLA-R25-300D/N4D4

Note:

Top clearance is primarily a maintenance rather than operational requirement. If top clearance is reduced future maintenance (if required) cost may increase due to need to move and then return unit to original position.

Enclosed room installation

■ SLA-R18-190D/N4A4: the minimum area = 25m^3.
■ SLA-R25-250D/N4D4, SLA-R25-300D/N4D4: the minimum area = 32.5m^3.

Unit dimension

Model	D	H
SLA-R18-190D/N4D4	510mm	2175mm
SLA-R25-250D/N4D4	640mm	1800mm
SLA-R25-300D/N4D4	640mm	2010mm